



USER GUIDE

65W GaN 3-Port Charger

Model / MPN KYT830-65W-CCA



65W

MAX OUTPUT

2 x USB-C

1 x USB-A

UK

3-PIN PLUG

READ FIRST Read this guide before use and keep it for future reference. Use only with compatible devices, cables and mains supplies.

ONLINE GUIDE For the latest version, visit <https://rcity.uk/user-guide.html>

Quick start

1. Inspect the charger, plug, socket and charging cable. Do not use anything damaged, loose, wet or contaminated.
2. Insert the charger fully into an accessible UK 3-pin wall socket.
3. Connect a suitable cable to USB-C1, USB-C2 or USB-A, then connect the device.
4. The device and charger select a supported charging profile automatically. Charging speed depends on the device, cable, protocol and ports in use.
5. When finished, disconnect the device, then unplug the charger by holding its body - never pull a cable.

FOR UP TO 65W Connect one compatible device to USB-C1 or USB-C2 with a USB-C cable rated for 65W or more. Disconnect other devices because available power is shared.

Choose a port

PORT	SINGLE-PORT MAX	BEST FOR
USB-C1	65W	Laptop, tablet, phone or handheld
USB-C2	65W	Laptop, tablet, phone or handheld
USB-A	36W	Compatible USB-A phone or accessory

Power sharing

PORTS IN USE	AVAILABLE OUTPUT
C1 + C2	C1 up to 45W; C2 up to 18W
C1 + A	C1 up to 45W; A up to 18W
C2 + A	15W shared across C2 and A
C1 + C2 + A	C1 up to 45W; 15W shared across C2 and A

Note: When another device is connected or removed, charging may briefly pause while power is reassigned.

Important safety information

STOP USE IMMEDIATELY Disconnect safely and stop using the charger if it becomes unusually hot, smells burnt, makes unusual noise, sparks, shows visible damage, has bent or loose pins, or has been exposed to liquid.

- Dry indoor use only. Keep away from water, condensation, sinks, baths and wet hands.
- Plug directly into a sound, accessible wall socket. Do not use a loose, damaged or overloaded socket.
- Allow air to circulate. Do not cover the charger or use it under bedding, soft furnishings, clothing or other heat-trapping material.
- Keep away from flames, heaters, prolonged direct sunlight and other heat sources.
- Use only undamaged cables and compatible devices. Do not force a connector into a port.
- Do not insert metal or other objects into the ports. Do not short-circuit, open, modify or attempt to repair the charger.
- Keep out of reach of young children and pets. This product is not a toy.
- Unplug before cleaning, during long periods of non-use, and before inspecting any suspected damage.

NORMAL WARMTH Some warmth during fast charging can be normal. Move the charger to a hard, open surface. If heat is excessive or accompanied by smell, discolouration, deformation or charging faults, stop use.

Care and storage

- Unplug from the mains and all devices, then allow the charger to cool.
- Wipe only with a soft, dry cloth. Do not use water, sprays, solvents or abrasive cleaners.
- Keep ports clean and dry. Store in a cool, dry place with the plug pins protected from impact.

Troubleshooting

ISSUE	WHAT TO TRY
No charge	Reseat both cable ends; try a known-compatible cable, device and wall socket; unplug the charger for 30 seconds, then reconnect.
Slow charge	Use USB-C1 or USB-C2 with one device and a suitably rated USB-C cable. Disconnect other devices and confirm the device supports a listed profile.
Repeated drop-outs	Try a different known-good cable and device. If the issue continues, stop use and contact support.

Technical specifications

ITEM	SPECIFICATION
Model / MPN	KYT830-65W-CCA
Input	110-240 V AC, 50/60 Hz, 1.5 A max
USB-C1	5 V DC/3 A; 9 V/3 A; 12 V/3 A; 15 V/3 A; 20 V/3.25 A (65W max). PPS: 3.3-11 V/5 A; 3.3-20 V/3 A.
USB-C2	5 V DC/3 A; 9 V/3 A; 12 V/3 A; 15 V/3 A; 20 V/3.25 A (65W max). PPS: 3.3-20 V/3 A.
USB-A	5 V DC/3 A; 9 V/3 A; 12 V/3 A (36W max).
C1 + C2	C1: 5 V/3 A, 9 V/3 A, 12 V/3 A, 15 V/3 A, 20 V/2.25 A. C2: 5 V/3 A, 9 V/2 A.
C1 + A	C1: 5 V/3 A, 9 V/3 A, 12 V/3 A, 15 V/3 A, 20 V/2.25 A. A: 5 V/3 A, 9 V/2 A.
C2 + A	5 V DC/3 A shared.
C1 + C2 + A	C1: 5 V/3 A, 9 V/3 A, 12 V/3 A, 15 V/3 A, 20 V/2.25 A. C2 + A: 5 V/3 A shared.

Disposal and recycling

ELECTRICAL RECYCLING Do not dispose of this charger with household rubbish. Take it to an appropriate electrical recycling collection point or follow your retailer or local authority's recycling guidance.

Support and product identification

REFERENCE	DETAILS
Support	enquiry@rcity.uk rcity.uk/support.html
eBay orders	Use the help, return or refund option inside the eBay order first.
Batch / lot	See product or packaging label: _____
Guide ID	UG-KYT830-65W-CCA-EN-GB Rev 1.0 23 August 2026

Any voluntary warranty is stated at checkout or in the marketplace listing. Your statutory rights are unaffected.